







Energizer Parts Catalog

1 (800) 531-5908

Call for current parts prices.




S20 (G357404) SH1 (G357454)

A	Module (2 Boards are connected)	G35748
B	Solar Panel (2W)	2A9859
C	Lens	2N1576
D	Printed Front Cover (S20)	2A9812
E	Enclosure Back	2N1578
F	Electronics Seal	2N1584
G	Fence & Earth Lead Set (Grn & Red)	2A1050
H	Battery Wire Set (Red & Blk)	2K0790
I	12V Battery (5AH)	APC1250
J	Bustle	2N1580
K	Bustle Clip	2N1589
L	Knurled Pin	4G0651
M	Switch Lever	2N1541
N	Switch Actuator	2N1548
O	Switch Clip	2N1542
P	Y Strip	2N1703
R	Foam Insert	4G0652
S	Terminal Bolt	4G0672
T	Black Knob	2N1565
U	Green Knob Cap	2N1154
V	Red Knob Cap	2N1075
	"O" Ring	4G2298
	Terminal Nut	5B2607
	Switch Seal	2N1552







S50 (G359404) SH2 (G359454)

A	Module (2 Boards are connected)	G35948
B	Solar Panel (5W)	2A9858
C	Lens	2N1575
D	Printed Front Cover (S50)	2A9813
E	Enclosure Back	2N1577
F	Electronics Seal	2N1584
G	Fence & Earth Lead Set (Grn & Red)	2A1050
H	Battery Wire Set (Red & Blk)	2K0790
I	12V Battery (5AH)	APC12100
J	Bustle	2N1580
K	Bustle Clip	2N1589
L	Knurled Pin	4G0651
M	Switch Lever	2N1541
N	Switch Actuator	2N1548
O	Switch Clip	2N1542
P	Y Strip	2N1701
Q	U Strip	2N1702
R	Foam Insert	4G0652
S	Terminal Bolt	4G0672
T	Black Knob	2N1565
U	Green Knob Cap	2N1154
V	Red Knob Cap	2N1075
	"O" Ring	4G2298
	Terminal Nut	5B2607
	Switch Seal	2N1552







B80 (G362504) BH2 (G362454)

A	Module	G362594
B	Transformer	2A7032
C	Energizer Cover (B80)	2A9777
	Energizer Cover (BH2)	2A9820
D	Energizer Base (B80)	2N1540
	Energizer Base (BH2)	2N1618
E	T-Post Clip	2N1544
F	Carrying Handle	2N1549
G	Face Label (Orange) (B80)	3B1881
	Face Label (Orange) (BH2)	3B1725
H	Battery Wire Set (Red & Blk)	2A1044
I	Fence & Earth Lead Set (Grn & Red)	G57300
J	Black Knob	2N5009
K	Green Knob Cap	2N5068
L	Red Knob Cap	2N5061
M	Fuse 1A	2M1221
O	Switch Lever	2N1541
P	Switch Actuator	2N1548
Q	Switch Clip	2N1542
R	Fence Terminals	4G0670
S	Terminal Bolt	4G0672
	"O" Ring	4G2298
	Terminal Nut	5B2607
	Bargraph Seal	2N1551
	Switch Seal	2N1552







B180 (G364504)

A	Module	G364594
B	Transformer	2A7028
C	Capacitor	2C0524
D	Energizer Cover	2A9777
E	Energizer Base	2N1540
F	T-Post Clip	2N1544
G	Carrying Handle	2N1549
H	Face Label (Orange)	3B1881
I	Battery Wire Set (Red & Blk)	2A1044
J	Fence & Earth Lead Set (Grn & Red)	G57300
K	Black Knob	2N5009
L	Green Knob Cap	2N5068
M	Red Knob Cap	2N5061
O	Switch Lever	2N1541
P	Switch Actuator	2N1548
Q	Switch Clip	2N1542
R	Fence Terminals	4G0670
S	Terminal Bolt	4G0672
T	Fuse 1A	2M1221
	Terminal Nut	5B2607
	Bargraph Seal	2N1551
	Switch Seal	2N1552
	"O" Ring	4G2298





B280 (G366504)

A	Module	G366594
B	Transformer	2A7028
C	Capacitor	2C0542
D	Energizer Cover	2A9777
E	Energizer Base	2N1540
F	T-Post Clip	2N1544
G	Carrying Handle	2N1549
H	Face Label (Orange)	3B1881
I	Battery Wire Set (Red & Blk)	2A1044
J	Fence & Earth Lead Set (Grn & Red)	G57300
K	Black Knob	2N5009
L	Green Knob Cap	2N5068
M	Red Knob Cap	2N5061
O	Switch Lever	2N1541
P	Switch Actuator	2N1548
Q	Switch Clip	2N1542
R	Fence Terminals	4G0670
S	Terminal Bolt	4G0672
T	Fuse 1A	2M1221
	"O" Ring	4G2298
	Terminal Nut	5B2607
	Bargraph Seal	2N1551
	Switch Seal	2N1552





M150 (G328504) MH2 (G328454)

A	Module	G328594
B	Transformer	2A7029
C	Power Supply Cord	2K0893
D	Energizer Cover (M150)	2A9780
	Energizer Cover (MH2)	2A9816
E	Energizer Base (M150)	2N1539
	Energizer Base (MH2)	2N1622
F	Fuse 1A	2M1221
G	Lightning Rod	4G0664
H	Face Label (Orange) (M150)	3B1878
	Face Label (Orange) (MH2)	3B1726
I	Terminal Bolt	4G0672
J	Black Knob	2N5009
K	Green Knob Cap	2N5068
L	Red Knob Cap	2N5061
N	LED Lens	2N1545
O	Fence Terminals	4G0670
	"O" Ring for Terminal Nut	4G2298
	Terminal Nut	5B2607








M300 (G380504) MH3 (G380454)

A	Module	G380584
B	Transformer	2A7029
C	Capacitor	2C0543
D	Power Supply Cord	2K0893
E	Energizer Cover (M300)	2A9778
	Energizer Cover (MH3)	2A9815
F	Energizer Base (M300)	2N1539
	Energizer Base (MH3)	2N1622
G	Fuse 1A	2M1221
H	Lightning Rod	4G0664
I	Face Label (Orange) (M300)	3B1877
	Face Label (Orange) (MH3)	3B1727
J	Terminal Bolt	4G0672
K	Black Knob	2N5009
L	Green Knob Cap	2N5068
M	Red Knob Cap	2N5061
N	Bar Graph Lens	2N1546
O	Fence Terminals	4G0670
	"O" Ring for Terminal Nut	4G2298
	Terminal Nut	5B2607



M600 (G381504)

A	Module	G381594
B	Transformer (Blue Shell)	2A7008
C	Capacitor	2C0505
D	Power Supply Cord	2K0840
E	Energizer Cover	2N1213
F	Energizer Base	2N1214
G	Lightning Rod	4G2275
H	Face Label (Orange)	2A9782
I	Main Front Label (Black)	3B1872
J	Terminal Bolt	4G2271
K	Black Knob	2N5009
L	Green Knob Cap	2N5068
M	Red Knob Cap	2N5061
N	Bar Graph Lens	2N1165
O	Power Indicator Lens	2N1222
P	Supply Panel	2N1216
Q	Capacitor Terminal	4G2273
R	Fence Interconnect Terminal	4G2272
	Fuse 1A	2M1221
	"O" Ring for Terminal Nut	4G2298
	Terminal Nut	5B2607



M1000 (G382504)

A	Module - Main Board	G382594
B	Module - Display Board	G382584
C	Transformer	2A7018
D	Capacitor	2C0518
E	Energizer Cover	2N1213
F	Energizer Base	2N1214
G	Supply Cord	2K0840
H	Lightning Rod	4G2275
I	Face Label (Orange)	2A9783
J	Main Front Label (Black)	3B1908
K	Terminal Bolt	4G2271
L	Black Knob	2N5009
M	Green Knob Cap	2N5068
N	Red Knob Cap	2N5061
O	Bar Graph Lens	2N1165
P	Power Indicator Lens	2N1222
Q	Supply Panel	2N1216
R	Capacitor Terminal	4G2273
S	Fence Interconnect Terminal	4G2272
	Fuse 500A	2M1389
	"O" Ring for Terminal Nut	4G2298
	Terminal Nut	5B2607

